



Comments: Scrub membrane and pipe boot with Lexcan Weathered Membrane Cleaner prior to welding.

If field membrane is not cut tight to vent pipe target piece must be installed.



Vent Stack - Hi-Tuff TPO Pipe Boot Roofing System Detail

Scale: Not to scale

Date: August, 2016

Detail No.: H-S-312