



- Comments:
1. Lexcan Batten Bar to be secured to parapet with approved fasteners on 15 cm (6") centres flush to top of insulation.
  2. Hi-Flex EPDM T-610 OverlayTape to be centred over Batten Bar and applied with either Hi-Flex EPDM PA-100 Primer or Hi-Flex EPDM SA-747 Splice Adhesive. Upper edge to be sealed with Hi-Flex EPDM Lap Sealant.



**Batten Bar Method - 2 (with Overlay Splice)**  
**Roofing System Detail**

Scale: Not to scale  
 Date: August, 2016  
 Detail No.: L-S-122