



COMMENTS: 1. EXTEND MEMBRANE 38 mm (1 1/2") BEYOND DRAIN BOLTS. PUNCTURE BOLT HOLES IN MEMBRANE. DO NOT CUT.
 2. FASTEN DRAIN FLANGE ON 25 cm (10") CENTERS AROUND CIRCUMFERENCE.



**Retrofit Roof Drain
 (with Clamping Ring)
 Roofing System Detail**

Scale: Not to scale
 Date: August, 2016
 Detail No.: L-S-316b