



Comments: Gutter straps must be secured into fascia. Never installed on top of nailer.

Fasteners must be embedded into nailers 38mm (1.5") min. Nailers to be secured appropriately to support a full gutter's weight requirement.

Membrane must be fully adhered from roof edge to first row of membrane fasteners.



Roof Edge (Gutter) Roofing System Detail

Scale: Not to scale

Date: August, 2016

Detail No.: H-S-202