

A) Dog-ear fold adhered with Primer/Adhesive

Step 1

Primer / Adhesive

Hi-Flex EPDM Membrane

Hi-Flex EPDM

Lap Sealant

Primer/Adhesive

Indicates fold in EPDM or LexFlash II

A) LexFlash II flashing adhered with Primer/Adhesive

B) Lap Sealant applied to all LexFlash II edges

Width*

Termination as Required

Height as specified

Step 2

Comments:

In cold temperature, use hot air gun to form LexFlash II.

*Width = 50 mm (2") wider than the width of dog-ear fold.



Field Fabricated Inside Corner 1 Roofing System Detail

Scale: Not to scale

Date: August, 2016

Detail No.: L-S-301