



- Comments:
1. Extend membrane 38mm (1 1/2") beyond drain bolts. Puncture bolt holes in membrane. Do not cut.
  2. Fasten drain flange on 25cm (10") centers around circumference.



## Retrofit Roof Drain (with Clamping Ring) Roofing System Detail

Scale: Not to scale

Date: August, 2016

Detail No.: P-S-321