



Comments: Pipe Flashing must extend minimum 200 mm (8") above roof flood level.



Vent Stack - Flashing to Pipe Roofing System Detail

Scale: Not to scale

Date: August, 2016

Detail No.: P-S-313