

FEATURES & BENEFITS

- Slip-resistant when wet or dry
- Covers 1000 ft² per roll
- Lighter and 10 times stronger than organic felt
- Does not absorb moisture
- Won't wrinkle or buckle when wet
- Printed with 5 5/8" installation lines
- Very easy to handle and install
- Very good UV protection and waterproofing; can be applied in all weather conditions


TECHNICAL DATA

LEXMAT SYNTHETIC ROOFING UNDERLAYMENT	
Length per roll	250 li. ft. (76.2 m)
Width per roll	48" (1.2 m)
Weight per roll	25 lbs
Rolls per skid	48
Coverage	1000 ft ² (92.9 m ²)
Tear strength (ICC-ES AC207)	PASS
Pliability at -10°C (ICC-ES AC207)	PASS no cracking or delamination

Approved CSA 123.3, ASTM D226 and ASTM E108 Class A (fire):
IC-207 pending

UTILISATION

1. The roof deck must be clean, smooth and dry before starting installation.
2. Lexmat synthetic roofing underlayment should be unrolled and laid flat to the roof deck, parallel to the eaves, starting at the bottom on the roof with the printed side up.
3. Lexmat synthetic roofing underlayment should overlap by 4 inches the underlying course and by 6 inches for the ending overlap.
4. Attach Lexmat synthetic roofing underlayment to the roof deck with roofing nails or staples having a 1-inch diameter plastic/metal cap. Use enough fasteners to safely hold the underlayment in place until the shingles application.



Guide lines every 5 5/8"

5. Space fasteners at 8 inches on center along course and end laps, and at 24 inches in the field of the sheets. In high wind zones, space fasteners at 4 inches on center along course and end laps, and at 12 inches in the field of the sheets, and check local building codes.

Lexmat synthetic roofing underlayment is a vapor retarder, so the airspace beneath the roof deck should be properly and thoroughly ventilated to avoid risk of moisture condensation.

Always follow safe roofing practices and applicable safety requirements.